

## STELLAR FlyPods



### **FlyPods usage time**

6.5 hrs usage time when fully charged.

Charge fully before first use.

### **Bluetooth pairing**

Activate the Bluetooth function on your device.

Open the case – the FlyPods will begin auto-pairing with each other.

The FlyPods LED will flash red and blue during device pairing mode.

Search for “STELLAR FlyPods” and connect them.

All systems are go!.

### **Single FlyPods usage**

Each of the FlyPods can be used independently.

### **FlyPods charging**

Place the FlyPods inside the case and let them charge automatically.

During charging time: the LED light on the FlyPods will turn solid red and the LED light on the case will turn white and alternate on/off while charging (breathing).

Both LED lights will turn off permanently once charging is completed.

Battery low: FlyPods LED light will flash red every 30 secs accompanied by an audio prompt.

Charging time: 48 mins (10 mins = 2.5 hrs usage time).

## **Case charging**

Plug the Type-C cable (provided) to an adapter or computer to charge the case.

During charging time: the LED light on the case will turn green and alternate on/off (breathing). The LED will turn solid green once charging of the case is completed.

Charging time: 2 hrs.

## **Calling / Music**

To answer / end a call: Tap on L/R FlyPod 2 times

To reject an incoming call: Touch and hold L/R FlyPod for 2 seconds until a prompt tone

To play/pause music: Tap on L/R FlyPod 2 times

To skip to the next song: Tap on the R FlyPod 3 times

To go back to the previous song: Tap on the L FlyPod 3 times

## **Voice assistant**

Touch and hold the L FlyPod for 2 secs a prompt sound to activate the voice assistant (ie. Siri) function. This function may not work on all devices.

## **Power off**

Method 1: Place the FlyPods back into the case.

Method 2: Touch and hold the FlyPods for 5 secs until the “power off” prompt.

Remark: The FlyPods will power off automatically if not paired with any device for 5 mins.

## **Resetting your FlyPods**

Place both FlyPods into the case.

Keep the case open and press the reset button on the case for 5 to 7 secs.

## **ANC function**

Transparency on: Long press the R FlyPod for 2 secs

ANC on: Long press the R FlyPod for 2 secs

ANC off: Long press the R FlyPod for 2 secs

## **ENC Technology**

The ENC (Environmental Noise Cancellation) algorithm cancels the background noise so that you can be heard crystal clear via voice calls. The FlyPods are equipped with 4 microphones and the ENC is activated by default during calls.

## **Avoiding hearing damage**

To prevent possible hearing damage, avoid listening at high volume levels for long periods.

## **Contact Us**

If you have any questions about this Manual, please contact us at [info@stellarstlr.com](mailto:info@stellarstlr.com).